

890-85XX Promatch® Dyes SB Stain

Product codes: 890-8500 Clear Base

890-8502 Yellow 890-8505 Brown 890-8506 Red 890-8508 Orange 890-8509 Blue 890-8510 Black 890-8511 Walnut 890-8512 Mahogany 890-8513 Oak 890-8514 Cherry 890-8515 Maple

890-8516 Pine

Viscosity N/A

Flash Point: $-4^{\circ}F (-20^{\circ}C)$ Density (lb/gal): ~ 6.8 Solid (% by weight): 0 - 2.0%Solid (% by volume): 0 - 1.0%Shelf Life (months): 24

Product Description:

The Promatch Dye line consists of dyes dissolved in a non-grain raising solvent blend. These products have brighter colors and better clarity than wiping and spray stains.

Uses:

Dyes are used as a first coat on wood to give bright, clear, transparent effects. It is adequate for interior exposure on expensive furniture, but is not designed for exterior exposure.

Environmental Data (as supplied): VOC less exempt lb/gal: < 7.5

VOC lb/gal: <1.7

VOC less exempt g/I:

VOC g/I:

VOC lb/lb Solid: < 26 VHAPs lb/lb Solid: <0.1

Note:

N/A

Application Data Suggested Uses: Wood Stain

Mixing Ratio: N/A
Suggested Uses: N/A
Application Viscosity: N/A
Reducer: 890-8500
Retarder: N/A
Clean-up Solvent: 800-5500
Recommended Wet
Film: N/A

Film:

Coverage: Wood substrate should be sanded with 120, 150 or 180 grit paper prior to

staining or coating. Wood must be well sanded and without large

imperfections.

Note:

N/A

Directions for use:

Surface Preparation:

Wood substrate should be sanded with 120, 150 or 180 grit paper prior to staining or coating. Wood must be well sanded and without large imperfections.

General Information:

Most of these products can be applied by spraying as received but can also be reduced any amount with 890-8500 clear base.

Toner penetrates deeply and cannot be worked in, like wiping stains, in order to achieve uniformity. Birch is especially suitable for Toner.

IMPORTANT: Product must be thoroughly agitated before use.

THE CUSTOMER IS RESPONSIBLE FOR FOLLOWING THE RECOMMENDED APPLICATION PROCEDURES. FAILURE TO ADHERE TO THE RECOMMENDATIONS GIVEN IN THIS DATA SHEET WILL LIKELY RESULT IN UNSATISFACTORY FILM APPEARANCE OR FILM FAILURE. THE COMPLETE COATING SYSTEM SHOULD BE CHECKED FOR REQUIRED PROPERTIES PRIOR TO THE START-UP OF PRODUCTION

Drying Times:		Room Temperature (20°C / 68°F)	Forced Drying Schedule (50°C / 122°F)
	Tack Free Time:	N/A	N/A
	Dry to Sand:	N/A	N/A
	Dry to Stack:	N/A	N/A

Note:

N/A

Dry times are greatly affected by film build, porosity of substrate, air movement as well as heat and humidity. Temperatures are based on actual board temperature. This may vary depending on length of time for boards to reach these temperatures. Minimum curing temperatures of 64°F/18°C must be maintained throughout the curing cycle to achieve the film integrity as stated in product features.

These products are designed for industrial use only. AkzoNobel views safety as a top priority. Please refer to Material Safety Data Sheet for information on the safe use of this product.

Values shown are calculated estimates and should not be construed as product specifications. We cannot anticipate all conditions under which this information and our products or the products of other manufacturers in combination with our products may be used. We accept no responsibility for results obtained by the application of this information or the safety and suitability of each such product or product combination for their own purposes. Unless otherwise agreed in writing, we sell the products without warranty, and users assume all responsibility and liability for loss or damage arising from the use of our products whether used alone or a combination with other products. Use of unapproved or reclaimed solvent blends may reduce film properties and is not recommended.

Akzo Nobel Coatings, Inc 1431 Progress Ave High Point, NC 27260 336-841-5111

Updated: 2024-05-19 01:00:16

Copyright 2021 AkzoNobel. All Rights Reserved. Chemcraft is a registered trademark of Akzo Nobel Coatings Inc.